























































№	Профиль	Размер, мм	Цена, руб.	№	Профиль	Размер, мм	Цена, руб.	№	Профиль	Размер, мм	Цена, руб.	
1		<b>Пм-22;</b> <b>(60x30)</b>	211	19		<b>Мс-10;</b> <b>(150x40)</b>	434	37		*	<b>Кс-6;</b> <b>(150x100)</b>	605
2		<b>Мс-10;</b> <b>(81x25)</b>	234	20		<b>Мс-18;</b> <b>(160x45)</b>	445	38		*	<b>Кс-29;</b> <b>(180x150)</b>	802
3		<b>Мс-19;</b> <b>(73x30)</b>	236	21		<b>Мс-21;</b> <b>(150x40)</b>	495	39		*	<b>Кс-7;</b> <b>(200x143)</b>	838
4		<b>Мс-13;</b> <b>(73x28)</b>	236	22		<b>Пд-4;</b> <b>(155x60)</b>	524	40		*	<b>Кс-36;</b> <b>(220x140)</b>	958
5		<b>Мс-6;</b> <b>(80x35)</b>	245	23		<b>Пд-10;</b> <b>(165x65)</b>	575	41		*	<b>Кс-30;</b> <b>(230x190)</b>	1025
6		<b>Пм-16;</b> <b>(89x37)</b>	307	24		<b>Пд-8;</b> <b>(140x70)</b>	588	42		*	<b>Кс-38;</b> <b>(250x150)</b>	1031
7		<b>Мс-7;</b> <b>(100x30)</b>	308	25		<b>Пм-18;</b> <b>(170x60)</b>	594	43			<b>Зм-2;</b> <b>(220x69x165)</b> под молдинги	388
8		<b>Мс-21;</b> <b>(100x30)</b>	353	26		<b>Пд-7;</b> <b>(170x70)</b>	652	44			<b>Зм-2;</b> <b>(260x145x195)</b> под карнизы	575
9		<b>Мс-5;</b> <b>(110x35)</b>	322	27		<b>Пм-7;</b> <b>(180x70)</b>	654	45			<b>Кн-1;</b> <b>(230x73x150)</b>	237
10		<b>Мс-18;</b> <b>(110x35)</b>	322	28		<b>Пд-9;</b> <b>(180x75)</b>	672	46			<b>Кн-2;</b> <b>(260x81x195)</b>	470
11		<b>Мс-7;</b> <b>(120x30)</b>	330	29		<b>Пм-1;</b> <b>(190x60)</b>	653	47			<b>Зм-3;</b> <b>(190x71x162)</b> под молдинги	388
12		<b>Мс-14;</b> <b>(120x40)</b>	347	30		<b>Кс-12;</b> <b>(190x70)</b>	697	48			<b>Зм-3;</b> <b>(230x135x198)</b> под карнизы	575
13		<b>Мс-21;</b> <b>(130x30)</b>	412	31		<b>Кс-4;</b> <b>(150x100)</b>	726	49			<b>Кн-7;</b> <b>(240x113x545)</b> на угол	1082
14		<b>Мс-18;</b> <b>(130x40)</b>	379	32		<b>Кс-17;</b> <b>(175x90)</b>	734	50			<b>Кн-9;</b> <b>(240x110x544)</b> на угол	1082
15		<b>Мс-23;</b> <b>(140x35)</b>	376	33		<b>Кс-6;</b> <b>(185x90)</b>	772	51			<b>Бн-7;</b> <b>(200x82x485)</b> на угол	905
16		<b>Мс-7;</b> <b>(145x35)</b>	388	34		<b>Пд-9;</b> <b>(180x95)</b>	776	52			<b>Бн-8;</b> <b>(200x83x485)</b> на угол	905
17		<b>Мс-16;</b> <b>(150x40)</b>	395	35		<b>Пм-17;</b> <b>(200x85)</b>	797	53			<b>Пл-1;</b> <b>(400x40)</b> на угол	1270
18		<b>Мс-19;</b> <b>(150x40)</b>	395	36		<b>Кс-7;</b> <b>(200x100)</b>	836	54			<b>Пл-3;</b> <b>(400x40)</b> на угол	1150

\* - карнизы под кровлю без отделки верхней полки. Есть в наличии торцованные карнизы окон и подоконники.